

Deaver N98 and J66 Modification Guide (DRIVERS SIDE ONLY)

Use this guide when installing any 2.5 Smoothie Shocks on your 05-23 Tacoma to avoid any possible damage to your shock bodies due to clearance issues.

A FEW WORDS ON PRODUCT SAFETY AND MESSAGING:

Motor vehicles and off road motor sports/use involve high levels of risks and variables including speed, terrain, overall suspension component choice, driver behavior and other variables. It follows that if you are unable to foresee every combination of variables and these installation instructions do not reflect all product safety information which may be required to reduce risk of accident or injury related to your body, vehicle and selected modifications.

Before installation, please review the following safety information and installation instructions. Within these Instructions important safety information is preceded by a signal word indicating the relative risk of injury.

The signal word means:

⚠️WARNING A hazardous situation which, if not avoided, could result in death or serious injury. You CAN be Killed or Seriously Hurt if you don't follow instructions.

⚠️WARNING Modified Suspension Components Have a Higher Risk of Roll-over or Other Accident

⚠️WARNING: HIGHER ROLLOVER RISK		
	Avoid Excessive Speeds, Abrupt Maneuvers, Surfaces/Obstacles Which May Induce a Tripping Moment. All Occupants Buckle UP & USE Supplemental Restraints.	

Read and follow all instructions and understand all safety messaging before beginning installation. This installation requires intermediate mechanical skills and should be performed by a professional mechanic with access to proper safety equipment, proper tools, a lift, and means of securing the vehicle.

Deaver - N98 & J66 (Driver's Side - Overview)



1.



2.

Using an angle grinder, carefully cut off the ears on the rear clip bolts. Do this before installing the leaf springs into the vehicle.

⚠️WARNING Use extreme caution and wear eye protection!!!

